

BOTTONI da CUCIRE / SEWING BUTTONS

BC600 ZAMA
ZAMAK

catalogo/catalogue



Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
33BC600/art.C438

lin. 14 - 16



29627
lin 16

COD. FORMA - FORM:
33BC600/art.C439

lin. 16 - 20 - 28 - 36 - 40



30395
lin 28

COD. FORMA - FORM:
33BC600/art.C441

lin. 20 - 24 - 28 - 32 - 36 - 40



31794
lin 32

COD. FORMA - FORM:
33BC600/art.C470

lin. 18 - 24



N1010
lin 24

COD. FORMA - FORM:
33BC600/art.C473

lin. 14 - 16 - 18



N1049
lin 18

COD. FORMA - FORM:
33BC600/art.C486

lin. 18 - 20 - 24 - 28 - 32 - 40



31116
lin 28

COD. FORMA - FORM:
33BC600/art.C490

lin. 16 - 18 - 20 - 24 - 28
32 - 36 - 40



30004
lin 32

COD. FORMA - FORM:
33BC600/art.C500

lin. 18 - 20 - 24 - 28 - 32



31145
lin 20

COD. FORMA - FORM:
33BC600/art.C501

lin. 20 - 24 - 28 - 30 - 32
36 - 40 - 44



30358
lin 40

001 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
33BC600/art.C509

lin. 24 - 28 - 32 - 36



30317
lin 28

COD. FORMA - FORM:
33BC600/art.C517

lin. 20 - 24 - 28 - 32 - 36



N1103
lin 28

COD. FORMA - FORM:
33BC600/art.C521

lin. 16 - 20 - 24 - 28
32 - 36 - 44



31941
lin 28

COD. FORMA - FORM:
33BC600/art.C535

lin. 15 - 18 - 20 - 24 - 32



30314
lin 32

COD. FORMA - FORM:
33BC600/art.C542

lin. 24 - 28 - 36



30302
lin 28

COD. FORMA - FORM:
33BC600/art.C549

lin. 24 - 28 - 32 - 36



N2308
lin 32

COD. FORMA - FORM:
33BC600/art.C561

lin. 24 - 28 - 36 - 44



27642
lin 28

COD. FORMA - FORM:
33BC600/art.C587

lin. 28 - 32 - 36



31175
lin 28

COD. FORMA - FORM:
33BC600/art.C598

lin. 24 - 28 - 32 - 36



29638
lin 28

002 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
33BC600/art.C609

mm 5 - 7 - 10 - 12



31506
mm 7

COD. FORMA - FORM:
33BC600/art.C624

lin. 16 - 20 - 24 - 28



29673
lin 28

COD. FORMA - FORM:
33BC600/art.C625


lin. 16 - 20 - 24 - 28



29906
lin 20

COD. FORMA - FORM:
33BC600/art.C652

lin. 24 - 28 - 32 - 36



N2760
lin 32

COD. FORMA - FORM:
33BC600/art.C675

lin. 16 - 18



N1076
lin 18

COD. FORMA - FORM:
33BC600/art.C710

lin. 14 - 16 - 18 - 20



31504
lin 20

COD. FORMA - FORM:
33BC600/art.C716

lin. 20 - 24 - 28 - 32
36 - 40 - 44



N2181
lin 28

COD. FORMA - FORM:
33BC600/art.C720

lin. 20 - 24 - 28 - 32
36 - 40



N2177
lin 32

COD. FORMA - FORM:
33BC600/art.C721

lin. 24 - 32 - 40



31359
lin 40

003 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
33BC600/art.C722

lin. 32 - 40 - 54



31360
lin 54

COD. FORMA - FORM:
33BC600/art.C723

lin. 32 - 40 - 48



31361
lin 48

COD. FORMA - FORM:
33BC600/art.C730

lin. 40



N3999
lin 40

COD. FORMA - FORM:
33BC600/art.C741

lin. 24 - 36



31793
lin 36

COD. FORMA - FORM:
33BC600/art.C749

lin. 24 - 28 - 32 - 36 - 40



N1004
lin 32

COD. FORMA - FORM:
33BC600/art.C753

lin. 22 - 26 - 30 - 36



28658
lin 30

COD. FORMA - FORM:
33BC600/art.C754

lin. 20 - 28 - 32 - 36



N2137
lin 28

COD. FORMA - FORM:
33BC600/art.C755

lin. 24 - 28 - 32 - 36



N2189
lin 32

COD. FORMA - FORM:
33BC600/art.C758

lin. 22 - 34 - 44



31508
lin 34

004 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
33BC600/art.C770

lin. 24 - 28 - 32 - 36



N1178
lin 32

COD. FORMA - FORM:
33BC600/art.C778

lin. 24 - 28 - 32 - 36



N2170
lin 32

COD. FORMA - FORM:
33BC600/art.C781

lin. 24 - 28 - 32 - 36



N1080
lin 32

COD. FORMA - FORM:
33BC600/art.C786

lin. 32



31505
lin 32

COD. FORMA - FORM:
33BC600/art.C789

lin. 24 - 28 - 32 - 36



N2140
lin 32

COD. FORMA - FORM:
33BC600/art.C886

lin. 24 - 28 - 32 - 36



29648
lin 32

COD. FORMA - FORM:
33BC600/art.C889

lin. 24 - 28 - 32 - 36 - 44



27723
lin 32

COD. FORMA - FORM:
33BC600/art.C933

lin. 24 - 32 - 36



30308
lin 36

COD. FORMA - FORM:
33BC600/art.C940

lin. 28 - 32 - 36 - 44



29653
lin 28

005 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
33BC600/art.C963

lin. 24 - 28 - 32 - 36 - 44



30388
lin 32

COD. FORMA - FORM:
33BC600/art.C979

lin. 15 - 18 - 20 - 24



31172
lin 20

COD. FORMA - FORM:
33BC600/art.C9019

lin. 24 - 32



31174
lin 32

COD. FORMA - FORM:
33BC600/art.C9042

lin. 24 - 32



31507
lin 32

COD. FORMA - FORM:
33BC600/art.C9393

lin. 30 - 48



30764
lin 30

COD. FORMA - FORM:
33BC600/art.C9999

lin. 32 - 36



29674
lin 36

COD. FORMA - FORM:
33BC600/art.C10225

lin. 24 - 32



31253
lin 32

COD. FORMA - FORM:
33BC600/art.C10936

lin. 24 - 32



30451
lin 32

COD. FORMA - FORM:
33BC600/art.C10938

lin. 24 - 32 - 36



30311
lin 36

006 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
47BC600/art.AA0213

lin. 24 - 28 - 32



N2416
lin 32

COD. FORMA - FORM:
47BC600/art.AA0246

lin. 18 - 20 - 24 - 28 - 32 - 36



31810
lin 36

COD. FORMA - FORM:
47BC600/art.AA0332

lin. 22 - 32 - 35 - 44



N2627
lin 35

COD. FORMA - FORM:
47BC600/art.AA0367

lin. 24 - 28 - 32 - 36 - 40



N2796
lin 32

COD. FORMA - FORM:
47BC600/art.AA0553

lin. 18 - 28 - 32 - 36



29197
lin 28

COD. FORMA - FORM:
47BC600/art.AA0583

lin. 18 - 24 - 28 - 32



31669
lin 32

COD. FORMA - FORM:
47BC600/art.AA0584

lin. 18 - 20 - 24 - 28 - 32



30009
lin 28

COD. FORMA - FORM:
47BC600/art.AA0587

lin. 16 - 18 - 24 - 28 - 32
36 - 40 - 44 - 50



N2644
lin 36

COD. FORMA - FORM:
47BC600/art.AA0610

lin. 18 - 24 - 28 - 32 - 36



31671
lin 36

008 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
47BC600/art.AA0750

lin. 20 - 24 - 32



N2843
lin 24

COD. FORMA - FORM:
47BC600/art.AA0757

lin. 24 - 32



30324
lin 32

COD. FORMA - FORM:
47BC600/art.AA0766

lin. 22 - 28 - 32 - 36
40 - 44



N2677
lin 32

COD. FORMA - FORM:
47BC600/art.AA0767


lin. 32 - 40 - 44



N2717
lin 32

COD. FORMA - FORM:
47BC600/art.AA0809

lin. 24 - 32 - 40



31670
lin 40

COD. FORMA - FORM:
47BC600/art.AA0818

lin. 24 - 32 - 36 - 44



31791
lin 36

COD. FORMA - FORM:
47BC600/art.AA0946


lin. 18 - 24 - 32



N2648
lin 32

COD. FORMA - FORM:
47BC600/art.AA0978

lin. 20 - 24 - 28 - 36 - 40



N2441
lin 28

COD. FORMA - FORM:
47BC600/art.AA1001

lin. 18 - 24 - 28 - 32
36 - 40 - 44



N2635
lin 36

009 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
47BC600/art.AA1068

lin. 24 - 32



29744
lin 32

COD. FORMA - FORM:
47BC600/art.AA1081

lin. 18 - 24 - 32



N2392
lin 24

COD. FORMA - FORM:
47BC600/art.AA1150

lin. 24 - 32 - 40



N2684
lin 40

COD. FORMA - FORM:
47BC600/art.AA1170

lin. 24 - 32 - 40



N2847
lin 24

COD. FORMA - FORM:
47BC600/art.AA1328

lin. 18 - 24 - 28 - 32



31150
lin 28

COD. FORMA - FORM:
47BC600/art.AA1338

lin. 28 - 36 - 44



N3142
lin 28

COD. FORMA - FORM:
47BC600/art.AA1351

lin. 28 - 36 - 44



N2523
lin 28

COD. FORMA - FORM:
47BC600/art.AA1353

lin. 28 - 36 - 40



30964
lin 28

COD. FORMA - FORM:
47BC600/art.AA1460

lin. 18 - 24 - 28 - 32
36 - 40 - 44



31541
lin 28

010 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:

47BC600/art.AA1531

lin. 28 - 36



N2672
lin 28

COD. FORMA - FORM:

47BC600/art.AA1532

lin. 28 - 36



N2525
lin 28

COD. FORMA - FORM:

47BC600/art.AA1670

lin. 14 - 16 - 18 - 20 - 24
28 - 32 - 36



31526
lin 28

COD. FORMA - FORM:

47BC600/art.AA1748

lin. 24 - 28 - 32 - 36



31685
lin 36

COD. FORMA - FORM:

47BC600/art.AA1795

lin. 24 - 28 - 32



N2656
lin 32

COD. FORMA - FORM:

47BC600/art.AA1956

lin. 28 - 32 - 36



32184
lin 36

COD. FORMA - FORM:

47BC600/art.AA2015

lin. 24 - 28 - 32 - 36 - 40
44 - 48 - 63



31812
lin 36

COD. FORMA - FORM:

47BC600/art.AA2074

lin. 18 - 24 - 28 - 32 - 36
40 - 44 - 48



31191
lin 32

COD. FORMA - FORM:

47BC600/art.AA2137

lin. 24 - 28 - 32 - 36 - 44



30901
lin 32

011 - BC600/ZM

Bottoni da Cucire - Gambo | Sewing Buttons - Shank

COD. FORMA - FORM:
47BC600/art.AA2160

lin. 18 - 24 - 28 - 36



N3997
lin 36

COD. FORMA - FORM:
47BC600/art.AA2208

lin. 30 - 36



32153
lin 36

COD. FORMA - FORM:
47BC600/art.AA2269

lin. 24 - 32



31792
lin 32

012 - BC600/ZM